







Event Tent Parts List		
Part #		Item
8105-SC		5' x 5' Commercial Event Tent Frame with Carry Bag and Stakes
8108-SC		8' x 8' Commercial Event Tent Frame with Carry Bag and Stakes
8110-SC		10' x 10' Commercial Event Tent Frame with Carry Bag and Stakes
8120-SC		10' x 20' Commercial Event Tent Frame with Carry Bag and Stakes
BGM10		Bag for 5' x 5', 8' x 8' and 10' x 10'
BGM20		Bag for 10' x 20'
WCC		Wheeled Carrying Case
HW23		Scissor Bar Nut & Bolt Assembly (for Center Scissor)
HW24		End Scissor Bar Bolt
MPP1		Push Pin
MCB20		Lower Center Block for 10' x 20' Scissor Junction
MUCB		Upper Center Pole Block
MLCB		Lower Center Pole Block
MDC		Center Pole Dome Cap
MILC20		Center Leg Cap 10' x 20' (Top scissor joint)
MILS20		Center Leg Socket 10' x 20' (Lower scissor joint)
MISB		Intermediate Scissor Block
MLA1		Corner Leg Assembly -- Complete
MLA2		Center Leg Assembly -- Complete
MLCC		Corner Leg Cap
MLL6		Lower Leg with Push Pin
MLU6		Upper Corner Leg with Scissor Block
MPCA1		Lower Center Pole
MPCA2		Upper Center Pole for 10' x 10' and 10' x 20'
MPCA3		Upper Center Pole for 8' x 8'
MPCA4		Upper Center Pole for 5' x 5'
MS5		Scissor Bar -- 2.5' for 5' x 5'
MSS5		Scissor Bar -- 4' for 8' x 8'
MSL5		Scissor Bar -- 5' for 10' x 10' and 10' x 20'



MLA1



MPCA1



MISB



MCB20




MDC



MPCA2

MPCA3

MPCA4



MLA2